



®PATENTED

Instructions for the DryFireMag® for PSA Micro Dagger

Your DryFireMag® is simple to use, but it must be installed correctly.

WARNING! Always keep the firearm pointed in a safe direction while following instructions, and there-after.

1. Remove factory magazine if installed.
2. Pull back the slide and lock it.
3. **Inspect chamber and barrel to make sure your firearm is clear of ammo.**
4. Release the slide. (The slide **MUST** be cycled prior to loading the DryFireMag®)
5. Align the DryFireMag® with the mag-well, and give the base a bump with the palm of your hand if necessary to get it introduced into the grip.
6. Continue pushing with the palm until you feel and hear the mag lock in place.
7. Confirm that the mag is locked in by giving it a tug downward.
8. It's READY TO GO!

STEPS 2-7 PICTURED BELOW:

#2 and #3



#4 and #5



#6



#7



Avoid racking the slide with the DryFireMag® inserted. If the DryFireMag® is not properly seated and the slide is racked, the DryFireMag® may get jammed in the gun.

When your dryfire session is over, just press the mag-release button, grasp the bottom of the DryFireMag® and pull it out. Point the firearm in a safe direction, and pull the trigger.

PLEASE NOTE: Due to the variability within firearms, even of the same base model, your DryFireMag® may need an adjustment to perform as expected. "No reset", or an unsatisfactory feel of the trigger-break, right out of the box is not necessarily indicative of a mag defect. See the backside of this document regarding adjustments that can be made to create the best simulation possible.

Be sure to register your DryFireMag® @ www.dryfiremag.com/dryfiremag-product-registration/



DryFireMag® is a registered trademark of DryFireMag, LLC

Rev. 06.26.26

PLEASE NOTE: Your **DryFireMag®** has been pre-set for optimal performance right out of the box for the stock **PSA Micro Dagger**. Customizations and model variations may require an adjustment to meet your unique application and simulation expectations.



To lighten pull, the coil spring will need to be changed. Your **DryFireMag®** has been tested and adjusted to the standard trigger pull of approximately **5.5#**. An extra spring is included for a lighter trigger pull. A Spring Kit is **not** recommended for this mag due to lack of optimal performance across an extended spring assortment.

(Remember to always wear safety glasses when changing springs)

To remove the standard spring, insert the tip of a small flat-head screw-driver between the spring retaining knob and the first coil, compress the spring slightly, and pry upwards. To insert the replacement spring, place one end over the spring retaining knob on the lever, compress the spring slightly, and push the other end into the spring pocket just opposite.

Trigger-Break
Adjustment



How to adjust pre-travel (trigger travel before simulated release of the firing pin)

- Locate the #3/32 Allen wrench and the top hole on the back of the magazine.
- To shorten the trigger pre-travel, turn the set screw clockwise 1/8 of a turn. Reinsert the DryFireMag® and test. If pre-travel is still not short enough, repeat adjustment and retest. Turn this adjustment **a maximum of one complete turn** unless specifically advised by your DryFireMag® technician.
- To lengthen the trigger pre-travel, turn the set screw counter clockwise 1/8 of a turn. Reinsert the DryFireMag® and test. If an even longer pre-travel is desired, repeat adjustment and retest. Turn this adjustment **a maximum of one complete turn** unless specifically advised by your DryFireMag® technician.

For personal assistance, contact DryFireMag® Toll Free at (844) 844-4600 or by email: TechSupport@DryFireMag.com

NOTE: DryFireMag® strongly recommends maintaining a frequent lubrication schedule per OEM protocol regarding lubrication points and products, especially when dry-firing with the DryFireMag. Failure to do so may result in inconsistent, or poor trigger reset functionality, as well as immoderate wear in trigger assembly parts.

Customer satisfaction is our #1 goal!

Satisfaction Guaranteed: If you are not completely satisfied with your **DryFireMag®**, you may return it within **30 days** of having received it for a full refund. Upon request, **DryFireMag®, LLC** will send a return label. We cannot provide postage for customers outside of the USA and its territories. Your refund will be issued when the product is received in an unaltered and undamaged condition.

Warranty: DryFireMag® will repair or replace your **DryFireMag®** at our option within 1 year of purchase for any malfunction of the **DryFireMag®** due to workmanship or faulty materials. Any malfunction due to tampering or physical damage will not be covered by this warranty. This will be determined at the sole discretion of DryFireMag, LLC. This warranty covers the original purchase price of the **DryFireMag®**. Contact us through the DryFireMag.com "Contact" page and choose the link that applies.

Anyone using the **DryFireMag®** assumes full responsibility for its use. DryFireMag LLC. assumes no responsibility for any damage to property, or personal injury due to any use of this device.

Be sure to **register your DryFireMag®** @ www.dryfiremag.com/dryfiremag-product-registration/