



DryFireMag® for Sig Sauer® P320 Instructions

WARNING!

*Because a live round may be in the chamber after a magazine has been removed, pull and lock the slide to perform a thorough chamber check. **Make sure your weapon is clear of ammo!** Release the slide. **The gun could still fire with a DryFireMag installed, if charged, and a bullet remains in the barrel.***

The mag for the Sig P320 will come with 2 "spacers" stacked on it. Remove at least one of the spacers, leaving or replacing the spacer needed for a flush fit with the bottom of your mag-well when locked in (typically, the tall spacer for 15 rnd. max capacity, and the short spacer for 17 rnd. max capacity frames).

Note: The spacer is required for consistent performance and "gun-safe" insertion of the mag.



After applying the correct spacer (if needed for a flush fit), introduce the **DryFireMag®** into the mag-well at the angle and orientation shown. **Note:** The **lever faces the rear** of the gun on this model mag.

Spacer



After the lever is in the well, rock the mag back into alignment with the grip, then push the mag with your palm all the way in until you hear and feel it "lock in". Pull down on the plate to confirm lock.



Aim in a safe direction, and you are ready to start practicing. You may detect a heavier-than-normal first pull as the striker was set during the chamber check.



Spacer outlined in bright green for delineation purposes only. Spacer is all black.

The **DryFireMag®** enables dry fire practice without having to rack the slide. Avoid racking the slide with the DryFireMag inserted. If the DryFireMag is not properly seated and the slide is racked, the DryFireMag may get jammed in the gun.

There are a few adjustments that can be made by the user. If the feel of the trigger-pull with the DryFireMag is not meeting your expectations, go to www.dryfiremag.com to **watch a video**, or refer to the back of this page to learn how to make adjustments for the best simulation possible. *If you need further assistance, or have questions, please contact us @ **1-844-844-4600**, or email: **TechSupport@DryFireMag.com**.*

Be sure to register your DryFireMag® @ www.dryfiremag.com/dryfiremag-product-registration/

PLEASE NOTE: Due to the wide range of firearm customizations available, your **DryFireMag®** may require some easy adjustments in order to meet your expectations. If you plan to use the **DryFireMag®** in more than one pistol, each one may require a unique **DryFireMag®** adjustment.

Your **DryFireMag®** has been pre-adjusted to have an approximate Trigger Pull-Weight of 6 lb.
To increase the feel/weight of the trigger pull, the *included* coil spring will need to be inserted.
Always wear safety glasses when handling springs.



To install the included spring, set one end of the coil over the lever's spring retainer knob, compress the spring slightly, then push the other end into the spring pocket. Manually operate the lever a few times to insure that the spring got seated properly. You may need to slightly advance the trigger break-point to get it back on target after installing the spring.

Adjusting the pre-travel, or the point of the simulated release of the firing pin

- Locate the 3/32 Allen wrench and the top hole on the **front** of the magazine.
- To shorten the trigger pre-travel, turn the set screw clockwise 1/8 of a turn. Reinsert the **DryFireMag®** and test. If a shorter pre-travel is still desired, repeat adjustment and retest. **Do not turn this adjustment more than one TOTAL turn.**
- To lengthen the trigger pre-travel, turn the set screw counter clockwise 1/8 of a turn. Reinsert the **DryFireMag®** and test. If a longer pre-travel is still desired, repeat adjustment and retest. **Do not turn this adjustment more than one TOTAL turn.**

*If you need further assistance, please contact us @ 1-844-844-4600,
or email TechSupport@DryFireMag.com.*

Customer satisfaction is our #1 goal!

Satisfaction Guaranteed: *If you are not completely satisfied with your **DryFireMag®**, you may return it **within 30 days** of having received it for a full refund. Your refund will be paid when the product is received by DryFireMag®, LLC unaltered and undamaged. Contact **DryFireMag®** at [Returns@DryFireMag.com](mailto>Returns@DryFireMag.com) for authorization and a return label.*



Warranty:

DryFireMag® will repair or replace at our option any **DryFireMag®** malfunctioning due to workmanship or faulty materials within one (1) year of purchase. This will be determined at the sole discretion of DryFireMag®, LLC. Tampering or physical damage will not be covered by warranty. This warranty covers the original purchase price of the **DryFireMag®**.

If a repair is needed, whether still under warranty or not, go to the DryFireMag.com "Contact Us" page, click on the "PRODUCT SUPPORT" square (the gear icon), and click on the TECH SUPPORT button to submit a form. You will be sent an RMA which includes a Payment Link. If you purchased from **DryFireMag.com**, and still under warranty, a return label will also be sent.

If the DryFireMag® is not under the one (1) year warranty, a nominal repair fee will apply.

Anyone using the **DryFireMag®** assumes full responsibility for its use. DryFireMag®, LLC assumes no responsibility for any damage to property or any injury due to any use of this device.

NOTE: **DryFireMag®** strongly recommends maintaining a frequent lubrication schedule per OEM protocol regarding lubrication points and products, especially when dry-firing with the **DryFireMag®**. Failure to do so may result in inconsistent, or poor trigger reset functionality, as well as immoderate wear in trigger assembly parts.