



® Patented

DryFireMag® for Sig Sauer® P365 Instructions

WARNING!

Check the pistol's chamber to **make sure no ammo is present before continuing!**

A live round may remain in the chamber after a magazine has been removed. Pull and lock the slide to perform a thorough chamber check. Make sure your weapon is clear of ammo! Release the slide.

- Apply the appropriate mag spacer to the **DryFireMag®** according to your P365 frame size.
- Insert the **DryFireMag®** into the mag-well until you hear and feel it lock into place.
- Aim the firearm in a safe direction. You are ready to start practicing. It's that easy!



DryFireMag® shown installed in SIG P365 Nitron Micro Compact with mag spacer installed.

Note: You may detect a heavier-than-normal first pull as the striker is initially released.

The **DryFireMag®** enables dry fire practice **without having to rack the slide**. Avoid racking the slide with the DryFireMag® inserted. If the **DryFireMag®** is not properly seated and the slide is racked, the **DryFireMag®** may get jammed in the gun.

When your dryfire session is over, just press the mag-release button, and the new "drop-free" feature of the **DryFireMag®** for the P365 should fall into your other catching hand. **Note:** Reload practice with **DryFireMags®** is discouraged due to the potential for damage to both internal and external components.

There are a few adjustments that can be made by the user. If you desire a different trigger pull, **go to www.dryfiremag.com to watch a demonstration video or refer to the back of this page.** If you need further assistance, or have questions, please contact us @ 1-844-844-4600, 208-702-7030, or email TechSupport@DryFireMag.com

Be sure to register your DryFireMag® @ www.dryfiremag.com/dryfiremag-product-registration/

PLEASE NOTE: Due to the wide range of firearm customizations available, your **DryFireMag®** may require some easy adjustments in order to meet your expectations. If you plan to use the **DryFireMag®** in different pistols of the same basic model, the **DryFireMag®** may even require a slightly different adjustment between the pistols.



Adjusting the amount of pre-travel, or the point of the simulated release of the firing pin:

- Locate the 3/32 Allen wrench and the top hole on the **front** of the magazine.
- To shorten the trigger pre-travel, turn the set screw clockwise 1/8 of a turn. Reinsert the DryFireMag® and test. If a shorter pre-travel is still desired, repeat adjustment and retest. **Do not turn this adjustment more than one TOTAL turn.**
- To lengthen the trigger pre-travel, turn the set screw counter clockwise 1/8 of a turn. Reinsert the DryFireMag® and test. If a longer pre-travel is still desired, repeat adjustment and retest. **Do not turn this adjustment more than one TOTAL turn.**

If you need further assistance, please contact us @ 1-844-844-4600, 208-702-7030, or email TechSupport@DryFireMag.com.

NOTE: DryFireMag® strongly recommends maintaining a frequent lubrication schedule per OEM protocol regarding lubrication points and products, especially when dry-firing with the DryFireMag. Failure to do so may result in inconsistent, or poor trigger reset functionality, as well as immoderate wear in trigger assembly parts.

Customer satisfaction is our #1 goal!

Satisfaction Guaranteed: *If you are not completely satisfied with your DryFireMag®, you may return it within 30 days of having received it for a full refund. Your refund will be paid when the product is received by DryFireMag®, LLC unaltered and undamaged. Contact DryFireMag® at returns@dryfiremag.com for authorization and a return label.*

Warranty

DryFireMag® will repair or replace at our option any **DryFireMag®** malfunctioning due to workmanship or faulty materials within one (1) year of purchase. This will be determined at the sole discretion of DryFireMag®, LLC. Tampering, disassembly, or physical damage will not be covered by warranty.

Disassembly will VOID your warranty. This warranty covers the original purchase price of the **DryFireMag®**.

If a repair is needed, whether still under warranty or not, go to the DryFireMag.com "Contact Us" page, click on the "Repair Request" button to submit a form. You will be sent an RMA. If you purchased from **DryFireMag.com**, a return label will also be sent.

If the DryFireMag® is not under the one (1) year warranty, a nominal repair fee will apply. The customer may request an email invoice when completing the repair form.

Anyone using the **DryFireMag®** assumes full responsibility for its use. DryFireMag®, LLC assumes no responsibility for any damage to property or any injury due to any use of this device.