



Instructions for DryFireMag® for S&W® model: M&P (9mm and 40 cal.) & SD9 VE

WARNING!

A live round may remain in the barrel after a magazine has been removed. Pull and lock the slide to perform a thorough inspection to make sure your weapon is clear of ammo! (A "charged" gun with a bullet in the barrel can fire with a DryFireMag installed!) Release the slide only after thorough inspection.

Position the **DryFireMag®** under the mag-well in the orientation shown in the picture. Once the head of the lever is in the mag-well, rock the mag back in alignment with the grip and push the mag in until you hear and feel it lock in.

Aim the firearm in a safe direction. You are ready to start practicing!

The **DryFireMag®** enables dry fire practice without having to rack the slide between trigger pulls.

Note: You may detect a heavier-than-normal first pull as the striker is initially released.

Note: Tactical Reload practice with your **DryFireMag®** where mags are flung onto the ground or hard floor is discouraged due to the potential for damage to both internal and external components.



Avoid racking the slide with the DryFireMag® inserted. If the **DryFireMag®** is not properly seated and the slide is racked, the **DryFireMag®** may get jammed in the gun.

When your dryfire session is over, just press the mag-release button, grasp the bottom of the **DryFireMag®** and pull it out.

There are a few adjustments that can be made by the user. Please see the back of this page for tips to adjust the mag to match the actual dry-fire trigger-pull, and break, of your specific firearm.

PLEASE NOTE: Since there are various modifications that can be made to different pistols, if your **DryFireMag®** does not function as expected, it is probably not due to a malfunction in the **DryFireMag®**, but to the wide range of variations in firearms. Because of this, the **DryFireMag®** may require adjustments to meet your particular application. If you have more than one pistol for which this mag is compatible, adjustments may need to be made between use in each one for best performance.

Be sure to register your DryFireMag® @ www.dryfiremag.com/dryfiremag-product-registration/

DryFireMag is a registered trademark of DryFireMag, LLC

Your **DryFireMag®** has been tested and adjusted to a trigger pull-weight of approx. 5^{1/2} lbs. A heavier coil spring has been included with your purchase (bagged with the Allen wrench) as a way to easily increase this weight by a modest amount.

Always wear safety glasses when inserting or extracting springs



To exchange the pre-installed spring with the heavier spring, first remove the existing spring by inserting a small flat-head screw-driver or flat file between the first and second coil, compress the spring, and pull it off the spring retaining knob, and continue to pull it up and out.

To insert the heavier spring, place one end of the spring on the lever post first, compress the spring against the post, then force the other end into the spring-retainer-pocket just opposite the post. Manually actuate the lever a few times to make sure that the spring is properly seated.



Adjusting pre-travel, or the point of the simulated release of the firing pin

Locate the 3/32 Allen wrench and the Set Screw in the **TOP** hole on the **Back** of the magazine.

To shorten the trigger pre-travel (cause an earlier break), turn the set screw **clockwise** 1/8 turn (45°). Reinsert the DryFireMag® and test. If a shorter pre-travel is still desired, repeat adjustment and retest. **Do not turn this adjustment CW more than 2 total turns.** Doing so may cause excessive pressure on the internal leaf spring, and result in no reset, or mag failure.

To lengthen the trigger pre-travel (cause a later break), turn the Set Screw **counter-clockwise** 1/8 of turn. Reinsert the DryFireMag® and test. If a longer pre-travel is still desired, repeat adjustment and retest. **Turning more than 1 total turn CCW will likely result in no reset.**

NOTE: DryFireMag® strongly recommends maintaining a frequent lubrication schedule per OEM protocol regarding lubrication points and products, especially when dry-firing with the DryFireMag. Failure to do so may result in inconsistent, or poor trigger reset functionality, as well as immoderate wear in trigger assembly parts.

*If you need further assistance, or have questions regarding adjustments,
please call 1-844-844-4240
or email TechSupport@DryFireMag.com*

Customer satisfaction is our #1 goal!

Satisfaction Guaranteed: If you are not completely satisfied with your **DryFireMag®**, you may return it **within 30 days** of having received it for a full refund. Your refund will be paid when the product is received by DryFireMag®, LLC unaltered and undamaged. If purchased from us, contact **DryFireMag®** at **returns@dryfiremag.com** for authorization and a return label.

Warranty

DryFireMag® will repair or replace at our option any **DryFireMag®** malfunctioning due to workmanship or faulty materials within one (1) year of purchase. This will be determined at the sole discretion of DryFireMag®, LLC. Tampering or physical damage will not be covered by warranty. This warranty covers the original purchase price of the **DryFireMag®**.

Service

If a repair is needed, go to the DryFireMag.com "Contact Us" page, click on the "PRODUCT SUPPORT" square (the gear icon), and click on the TECH SUPPORT button to submit a form. You will be sent an RMA which, unless under warranty, will include a Payment Link for the nominal repair fee. If under warranty, and purchased from **DryFireMag.com**, a return label will also be sent.

*Anyone using the **DryFireMag®** assumes full responsibility for its use. DryFireMag®, LLC assumes no responsibility for any damage to property or any injury due to any use of this device.*